

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-22718
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. K-4666
7. Lease Name or Unit Agreement Name Sun State
8. Well No. #1
9. Pool name or Wildcat Bagley Permo Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator Read & Stevens, Inc.	
3. Address of Operator P.O. box 1518, Roswell, New Mexico 88202-1518	
4. Well Location Unit Letter <u>P</u> : <u>554</u> Feet From The <u>FSL</u> Line and <u>554</u> Feet From The <u>FEL</u> Line Section <u>7</u> Township <u>11S</u> Range <u>33E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4311.5 GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Read & Stevens, Inc. proposes to plug & abandon the subject well as follows:

- 1) Set a CIBP @8,600' above Wolfcamp perfs & dump 35' of cmt on top.
- 2) Set a 150' cmt plug across the top of the Tubbs formation f/7,500-6,000'.
- 3) Free point 5 1/2" csg & attempt to cut & pull f/below the 8 5/8" csg shoe.
- 4) Set 150' cmt plug half in & half out of 5 1/2" csg stub.
- 5) Set 150' cmt plug across 8 5/8" csg shoe f/4,700-3,200' this plug is also across the top of the San Andres.
- 6) Free point 8 5/8" csg & cut & pull f/below the 12 3/4" surf csg.
- 7) Set cmt plug in 8 5/8" csg stub & cover the top of the Salt @1,793'.
- 8) Set 100' cmt plug over the 12 3/4" csg shoe f/420-320'.
- 9) Cut off WH & set 50' cmt surf plug & install dry hole marker. Back fill, level & reclaim location.

Notify the OCD 24 hrs prior to MIRU for plugging operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Petroleum Engineer DATE February 26, 1996  
TYPE OR PRINT NAME John C. Maxey, JR. TELEPHONE NO. 505-622-3770

(This space for State Use)  
ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

FEB 29 1996