

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>K-5442</b>
7. Unit Agreement Name -
8. Farm or Lease Name <b>T. P. State</b>
9. Well No. <b>2</b>
10. Field and Pool, or Wildcat <b>Inbe, Penn</b>
12. County <b>Lea</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator <b>Tom Brown Drilling Company, Inc.</b>
3. Address of Operator <b>P.O. Box 5706, Midland, Texas 79701</b>
4. Location of Well UNIT LETTER <b>F</b> <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>25</b> TOWNSHIP <b>10-S</b> RANGE <b>33-E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>Unknown</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Bough "C" perforations in this well are 9919' to 9929'. Will set C.I. Bridge Plug at 9800' and spot 2 sack cement plug on top of same. Will spot following cement plugs:

30 sack plug at 4 1/2" casing stub if below top of San Andres.  
40 sack plug across 8 5/8" casing shoe at 3950'.  
25 sack plug at 8 5/8" casing stub.  
25 sack plug at 12 3/4" shoe at 350'.  
10 sack plug at surface with marker.

(Mud laden fluid will be left in hole.)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGN Thomas C. Brown TITLE President DATE 12-15-71

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE DEC 17 1971

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

1957

CHL. COMM. AT. C. 10001.  
HALL, L. M.