

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN THIS DATE
(Indicate date of submission on reverse side)Form approved.
Budget Bureau No. 42 H1424
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR M & G Oil, Inc.	8. FARM OR LEASE NAME Coll Federal Comm
3. ADDRESS OF OPERATOR P.O. Box 766 Tatum, New Mexico 88267	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FNL and 1980' FEL Sec. 8, T-9-S, R-35-E Lea County, New Mexico	10. FIELD AND POOL, OR WILDCAT Vada Penn
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4199' KB
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 8, T-9-S, R-35-E
	12. COUNTY OR PARISH Lea
	13. STATE N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Run tubing with bit on bottom and attempt to clean out restriction in casing at approximately 6050' depth.
2. If unsuccessful, run cement retainer and set 50' above maximum depth attainable. Squeeze cement with 100 sacks cement to a maximum pressure of 1500 psi.
3. Load casing with salt gel mud.
4. Burst 5 1/2" casing at 4043' depth opposite 8 5/8" casing shoe and spot 100' cement plug straddling this point. Tag top of cement.
5. Salvage 5 1/2" casing from approximately 2313' depth opposite top of salt section and spot 100' cement straddling this point. Tag top of cement.
6. Salvage 8 5/8" casing from free point anticipated to be at 800' depth and spot 100' cement plug straddling top of 8 5/8" casing. Tag top of cement.
7. Spot 100' cement plug straddling 13 3/8" shoe at 350' depth. Tag top of cement.
8. Spot 50' cement plug at surface and erect dry hole marker.
9. Fill mud pit and cellar and clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Wm. GroesbeckTITLE Vice PresidentDATE 11-25-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

12-9-86

RECEIVED
DEC 12 1995
OCD
HOBBS OFFICE