

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
BIA Oil Producers		Battles 687 Ltd.
3. Address of Operator		9. Well No.
104 S. Pecos Midland Texas 79701		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER "B" , 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 7 TOWNSHIP 9-S RANGE 36-E NMPM.		Vada-Penn
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4106' G. L.		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

## Proposed procedure:

Call NMOCC - Hobbs (505/393-6161) 24 hr. advance.

Hole to be filled w/mud laden fluid.

Lay down 2" tbg & Model "R" pkr.

Set CIBP @ 9800' w/3 sx cmt on top.

Cut & pull 5-1/2" csg. T/C @ 8395'.

Set 50 sx cmt @ 5518' Glorietta.

Set 50 sx cmt @ 4120 Base intermediate.

Cut & pull 8-5/8" csg.

Set 50 sx cmt on 8-5/8" stub.

Set 50 sx cmt @ 370' Base surface.

Set 10 sx cmt @ surface.

## Install dry hole marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James Jones TITLE Production Clerk DATE \_\_\_\_\_

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE DEC 26 1972  
 CONDITIONS OF APPROVAL, IF ANY: