

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OH. <input checked="" type="checkbox"/> GAS <input type="checkbox"/> WELL <input checked="" type="checkbox"/> WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. NM 0127905
2. NAME OF OPERATOR M & G Oil, Inc.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 66 Tatum, New Mexico 88267	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FNL and 660' FEL Sec. 12, T-9-S, R-35-E Lea County, New Mexico	8. FARM OR LEASE NAME Morton Federal
14. PERMIT NO.	9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	10. FIELD AND POOL, OR WILDCAT Vada Penn
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 12, T-9-S, R-35-E
	12. COUNTY OR PARISH 13. STATE Lea N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	(Other) <input type="checkbox"/>

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set cast iron bridge plug at 9739' (100' above 5½" casing perforations at 9839-61'). Cap with 35' of cement using dump bailer.
2. Run tubing to bottom and load casing with salt gel mud. Pull out of hole with tubing.
3. Set cast iron bridge plug in 5½" casing at 4150' (100' below the 8-5/8" casing shoe at 4050' depth). Burst casing at 4100' depth (50' below 8-5/8" casing shoe).
4. Run tubing to 4100' and spot 75 sacks cement. Pull out of hole with tubing.
5. Squeeze away cement with 1500 PSI casing pressure.
6. Tag top of cement with wire line to assure that a minimum of 100' of cement is left on top of bridge plug.
7. Burst casing with nitro shot at 2285' depth (at top of salt section).
8. Run tubing to 2335' and spot 75 sacks cement. Pull out of hole with tubing.
9. Squeeze away cement with 1500 pounds casing pressure.
10. Tag top of cement with wire line to assure that a minimum of 100' of cement is left inside 5½" casing above top of salt section.

18. I hereby certify that the foregoing is true and correct

SIGNED Wm. B. Svec TITLE Vice President DATE 8-1-86

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

cc: R 8-1-86

RECEIVED
AUG 6 1986
O.C.S.
HOBB'S OFFICE

11. Salvage any free 5½" casing above top of salt section
12. Run tubing to a point 50' below top of 5½" casing.
Spot 25 sacks cement at this point to leave a 100' cement
plug straddling top of 5½" casing.
13. Spot 10 sack cement plug inside 8-5/8" casing at surface.
14. Erect dry hole marker.
15. Fill pits and cellar. Level and clean location.