STATE OF NEW MEXICO

ENERGY AND MINIERALS DEPARTMENT

ביים ביים ויוויז בייאבט טפי		4 1 A I C
-6. 0/ CO-120 SECEIVED	1	•
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR	1	

OIL CONSERVATION DIVISION P. O. BOX 2088 SANTA FE, NEW MEXICO 87501

Form C-103 Revised 10-1-78

U.S.G.S.	Sa. Indicate Type of Lease
LAND OFFICE	State X
OPERATOR .	
La control of the con	5. State Oil & Gas Lease No.
	K-2129
SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OF PLUG BACK TO'A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT _" (FORM C-101) FOR SUCH PROPOSALS.)	
1.	7. Unit Agreement Name
OIL ASS OTHER- Water Injection Well	•
2. Name of Operator	Flying "M" (SA) Uni
	B. Farm or Lease Ivame
Coastal Oil & Gas Corporation	Flying "M" (SA) Unit T
3. Address of Operator	9. Well No.
P. O. Box 235, Midland, Texas 79702	1
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER H 2200 PEET FROM THE NORTH LINE AND 600 FEET FROM	
DHIT LETTER FEET PROM THE LINE AND FEET PROM	Flying "M" (SA)
D 16	
THE East LINE, SECTION 16 TOWNSHIP 95 RANGE 33E	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4368.5' GR	Lea ()
16. Check Appropriate Box To Indiana Name of Nation D	
Check Appropriate Box To Indicate Nature of Notice, Report or Other	
NOTICE OF INTENTION TO: SUBSEQUENT	REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON COMMENCE DRILLING OPHS.	PLUG AND ABANDONMENT X
PULL OR ALTER CASING CAMENT JOS CASING TEST AND CEMENT JOS	TOO AND ASSAUGHMENT IL
	_
OTHER	
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including e	
work) SEE RULE 1103.	stimated date of starting any proposed
1. Set retainer at 4250' and squeeze perforations 4504-44' with 100 sac	ks cement. Displaced
hole with 9.5 ppg 35 vis. mud.	•
2. Spot 50 sacks cement plug 2700-2560'.	
3. Spot 50 sacks cement plug 1950-1810' (top of salt at 1950').	
4. Perforate 8-5/8" casing at 450'.	
5. Cut off wellhead and weld on swage to $8-5/8$ " casing. Mix and pump 1	
cement. Cement circ. to surface. Install P&A marker. Work complete	ed on 11-20-84.
•	
13-3/8" casing at 400'	
8-5/8" casing at 4620'	
•	

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

B. L. Smith Boldy Smith

Petroleum Engineer

January 11, 1985