

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-2129	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name Flying M (SA) Unit
2. Name of Operator Coastal Oil & Gas Corporation		8. Farm or Lease Name Flying M (SA) Unit, Tr.
3. Address of Operator P. O. Box 235, Midland, Texas 79702		9. Well No. 1
4. Location of well UNIT LETTER <u>H</u> <u>2200</u> FEET FROM THE <u>North</u> LINE AND <u>600</u> FEET FROM THE <u>East</u> LINE, SECTION <u>16</u> TOWNSHIP <u>9S</u> RANGE <u>33E</u> N.M.P.M.		10. Field and Pool, or Whichever Flying M (SA)
15. Elevation (Show whether DF, RT, GR, etc.) 4368.5' GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set retainer at 4400' and squeeze perforations 4504-44' with 100 sacks cement. Displace hole with 9.5 ppg 35 viscosity mud.
- Spot 50 sacks cement plug 2700-2560'.
- Spot 50 sacks cement plug 1950-1810' (top of salt at 1950').
- Perforate 8-5/8" casing at 450', set retainer at 350' and squeeze with 100 sacks cement.
- Cut off casing 5' below ground. Spot 10 sacks cement, weld steel plate on casing top and install marker.

Note: 13-3/8" casing at 400' with 400 feet³ cement (cement returns).
8-5/8" casing at 4620' with 300 feet³ cement.

COPIES OF THIS REPORT
TO BE APPROVED
FOR THE CASE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED P. J. Wadd TITLE Production Operations Supervisor DATE September 10, 1984

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

TITLE

DATE

SEP 12 1984