

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

HOBBS OFFICE D. C. C.

APR 28 11 10 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-2790

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Major, Giebel & Forster	8. Farm or Lease Name Sinclair-Southland State
3. Address of Operator 1126 Vaughn Building, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER L , 510 FEET FROM THE West LINE AND 1980 FEET FROM South LINE, SECTION 31 TOWNSHIP 10-S RANGE 34-E NMPM.	10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

35 sx cement set from 10,065 to 9994'.
25 sx cement set from 9103 to 9017'.
25 sx cement set from 7784 to 7698'.
25 sx cement set from 5496 to 5410'.
25 sx cement set from 4094 to 4004'.
Cut off 8 5/8" casing at 1315'.
25 sx cement set from 1355 to 1293'.
25 sx cement set from 407 to 366'.
10 sx cement set at surface. Welded plate over top. Put up dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *A. J. Siebel* TITLE Partner DATE 4/28/69
APPROVED BY *John W. Runyon* TITLE Geologist DATE JUN 4 1969
CONDITIONS OF APPROVAL, IF ANY: