

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-2716	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Union Texas Petroleum Corporation		New Mexico "8"
3. Address of Operator		9. Well No.
1300 Wilco Building - Midland, Texas - 79701		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM		Undesignated
THE <u>East</u> LINE, SECTION <u>8</u> TOWNSHIP <u>10-S</u> RANGE <u>33-E</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4205 GL		Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- (1) 8 5/8" surface csg. set @ 354', cemented w/350 sx., circulated, no expected recovery.
- (2) 4 1/2" production csg. set @ 4498', cemented w/300 sx., top of cement @ 3420'.
- (3) Csg. Perforations @ 4464' to 4478' (56 holes), 4429' to 4450' (42 holes)
- (4) Propose to spot 25 sx. cement plug from 4478' to 4228'.
- (5) Cut 4 1/2" csg. off @ free pt. Approx. 3000'-3200' - Spot 35 sx. cement plug 100' in 4 1/2" csg. stub & 100' above.
- (6) Spot 35 sx. Cement plug 100' below & 100' in 8 5/8" csg.
- (7) Spot 10 sx. Cement plug @ surface - weld on 1/2" steel plate.
- (8) Install dry hole marker in accordance with regulations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Operations Supt.-Western Area DATE March 12, 1971

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: