

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRI. ATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM0149818

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Wolf Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

VADA PENN

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 5, T-9-S, R-35-E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

M & G Oil, Inc.

3. ADDRESS OF OPERATOR

P.O. Box 766 Tatum, New Mexico 88267

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

660' FSL and 1980' FEL

Sec. 5, T-9-S, R-35-E

Lea County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set cast iron bridge plug at 9672' (100' above 5½" casing perforations). Cap with 35' of cement and load hole with salt gel mud.
2. Spot 150' cement plug inside 5½" casing straddling top of Wolf- camp at 8850' depth. (top of cement outside 5½" casing is at 8640' by temperature survey). Tag top of cement.
3. Burst 5½" casing at top of Tubb at 6930' and spot 150' cement plug straddling this point. Tag top of cement.
4. Burst 5½" casing at 8 5/8" casing shoe at 4060' and spot 100' cement plug straddling this point. Tag top of cement.
5. Burst 5½" casing at top of salt section at 2246' and spot 100' cement plug straddling this point.
6. Salvage 5½" casing at a point below the 13 3/8" casing shoe at 372' depth and above the cement plug inside the 5½" casing covering top of salt section.
7. Spot 100' cement plug straddling top of 5½" casing. Tag top of cement.
8. Burst 8 5/8" casing at the 13 3/8" casing shoe at 372' depth and spot 100' cement plug straddling this point. Tag top of cement.

Cont. next page

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Vice President

DATE 9-23-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 29 1986

OFFICE
HOBBS