N. M. UIL BURG. BOMBRIDGE	•
HUتطS, NEW MEXICO 88 • Form 9-331	240 Form Approved. Budget Bureau No. 42-R1424
Dec. 1973 UNITED STATES DEPARTMENT OF THE INTERIOR	5. LEASE NM-0557837
GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different	7. UNIT AGREEMENT NAME
	Midwest F Federal
2. NAME OF OPERATOR	9. WELL NO.
Amoco Production Company 3. ADDRESS OF OPERATOR	10. FIELD OR WILDCAT NAME Vada Penn
P. O. Box 68, Hobbs, New Mexico 88240 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 1	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
below.) AT SURFACE: 1980' FSL X 1980' FWL, Unit K	12. COUNTY OR PARISH 13. STATE
AT TOP PROD. INTERVAL: Sec. 26 (NE/4,SW/4) AT TOTAL DEPTH:	Lea NM 14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICI REPORT, OR OTHER DATA	E, 15. ELEVATIONS (SHOW DF, KDB, AND WD) 4312 ' DF
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF: TEST WATER SHUT-OFF	(NOTE: Report results of multiple completion or zone change on Form 9-330.)
 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent details, and give pertinent details, and give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* Propose to plug and abandon as follows: (Notify - MMCCD²24 hrs. prior to commencing operation). Set a cast iron bridge plug at apx. 8630' and cap with 35' of class C neat cement. Spot 21 bbl 10# brine water with 25# gel/bbl. Run freepoint survey and cut 5-1/2" casing apx. 100' above freepoint. Pull 5-172" casing. Spot 25 sacks class C neat cement 50 in/out of 5-1/2" casing stub. Spot 215 bbl 10# brine water with 25# gel/bbl. PPUII up and spot 50 sacks class C neat cement in/out of 8-5/8" casing shoe set at 3925'. Spot 55 bbl 10# brine water with 25# gel/bbl. Run freepoint. Urop of cement apx. 7800') PUII 8-5/8" casing apx. 100' above freepoint. (Top of cement apx. 7800') PUII 8-5/8" casing. Spot 50 sacks class C neat cement in/out of 8-5/8" casing stub. Spot 310 bbl 10# brine water with 25# gel/bbl. Pull up and spot 50 sacks class C neat cement in/out of 8-5/8" casing stub. Spot 310 bbl 10# brine water with 25# gel/bbl. Pull up and spot 50 sacks class C neat cement to plug at (over) SubsUttart State with 25# gel/bbl. Spot 10 sacks class C neat cement to plug at (over) SubsUttart State with 25# gel/bbl. Spot 10 sacks class C neat cement to plug at (over) SubsUttart State with 90 den, Rm 21.150 1-F.J.Nash, HOU, Rm_{bet} 206 1-CLP_{Ft}. IB. Thereby certify that the forgoing is true and correct score of the space for Federal or State office use)	