

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-23471-0001
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LC-1796-1
7. Lease Name or Unit Agreement Name  State AR
8. Well No. 3
9. Pool name or Wildcat Echols (Devonian)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3956' KB

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Lynx Petroleum Consultants, Inc.
3. Address of Operator P. O. Box 1979, Hobbs, NM 88241	4. Well Location Unit Letter L : 660 Feet From The North Line and 990 Feet From The West Line Section 2 Township 11S Range 37E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3956' KB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

11 3/4" @ 353' 350 sx circ.  
8 5/8" @ 5000' 1120 sx circ.  
5 1/2" liner from 4799-11500'  
Perfs: 11260-11310'

1. Set CIBP capped w/35' cement at 11200'.
2. Load hole w/10# salt gel 25# per barrel.
3. Spot 100' plug @ 7700-7600'.
4. Spot 100' plug 50' in and 50' out of liner top @ 4799' and tag.
5. Spot 100' plug to top of salt 2200-2100'.
6. Spot 100' plug 400-300'.
7. 10 sx surface plug.
8. Install marker and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Marc Z... TITLE President DATE 3/15/91

TYPE OR PRINT NAME TELEPHONE NO

(This space for State Use)

APPROVED BY TITLE DATE

CONDITIONS OF APPROVAL IF ANY