| Form | 9-331 |
|------|-------|
| (May | 1963 |

UN"ED STATES DEPARTME... OF THE INTERIOR (Other instruction verse side)

SUBMIT IN TRIP \TE* reForm approved. Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO. 6. IF INDIAN, ALLOTTE OR TRIBE NAME

| GEOLOGICAL SURVEY | | | | | |
|-------------------|---------|-----|---------|----|-------|
| SUNDRY | NOTICES | AND | REPORTS | ON | WELLS |

| | (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.) | | |
|----|--|--|--|
| 1. | OIL GAS OTHER | 7. UNIT AGREEMENT NAME | |
| 2. | NAME OF OPERATOR ROGER Hanks | 8. FARM OR LEASE NAME | |
| 3. | c/o Hobbs Pipe & Supply, Box 2010, Hobbs, N. M. 8824 | 9. WELL NO. | |
| 4. | LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface | 10. FIELD AND POOL, OR WILDCAT Allison Ponn | |
| | 660' F8L & 660' FEL | 11. SHO., T., B., M., OR SLR. AND SURVEY OR AREA 12-9-36 | |

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)

12. COUNTY OR PARISH 13. STATE Lea N. M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

| NOTICE OF INTENTION TO: | | SUBSEQUENT REPORT OF: | | | | |
|---|--|---|----------|--|--|---|
| TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) | | PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON® CHANGE PLANS | <u>x</u> | WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING (Other) (NOTE: Report results of | REPAIRING WELL ALTERING CASING ABANDONMENT* multiple completion on Well on Report and Log form.) | - |
| | | // | | Completion of Recomplets | | - |

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- 1. Spot a 100' plug to cover all existing perforations.
- 2. Load hole w/mud-laden fluids.

- 3. Spot a 100' plug at 5-1/2 casing stub, approx. 7000'.
 4. Spot a 100' plug in and out of base of 8-5/8 casing, 4180'.
 5. Spot a 100' plug in and out of 8-5/8 casing shoe, approx. 1000'
 6. Spot a 100' plug at base of surface casing, 400'.
- 7. Spot a 10 sx plug at surface and erect a 4" regulation marker.

AMENDMENT

- 1. Cement plug over perforations should be minimum of 25 sacks.
- Place additional 100 foot cement olug in interval 5509-5600 feet.

| HOSES PIPE SUPPLY COMPANY SIGNED STARLLY SALES By: humne | MENT | 1/17/73 |
|--|--------|--------------|
| (This space for Federal or State office use) | ADDI | J XS AMENDED |
| APPROVED BY TITLE CONDITIONS OF APPROVAL, IF ANY: | JAN I | 9 197 DATE |
| *** | AKINUR | 2. BROWN |

"See Instructions on Reverse Side $-\mathcal{D}^{(S)RC}$