

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE  
(Other instructions on  
reverse side)Form approved.  
Budget Bureau No. 42-R1424.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

|  |  |   |  |
|--|--|---|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>   |  | 7. UNIT AGREEMENT NAME  |  |
| 2. NAME OF OPERATOR<br>The Maurice L. Brown Company  |  | 8. FARM OR LEASE NAME<br>Midwest Fed.                                 |  |
| 3. ADDRESS OF OPERATOR<br>Suite 200, Sutton Place Bldg. Wichita, Kansas 67202  |  | 9. WELL NO.<br>1  |  |
| 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.<br>See also space 17 below.)<br>At surface Unit Letter J, 1980' from South line, 1980' from East line. |  | 10. FIELD AND POOL, OR WILDCAT<br>Vada Penn                           |  |
| 14. PERMIT NO.<br>GR 4290.6'   |  | 11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA<br>Sec. 5, T9S, R34E |  |
| 15. ELEVATIONS (Show whether DF, RT, or, etc.)<br>GR 4290.6'   |  | 13. STATE<br>N.M.   |  |

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

|                     |                      |
|---------------------|----------------------|
| TEST WATER SHUT-OFF | PULL OR ALTER CASING |
| FRACTURE TREAT      | MULTIPLE COMPLETE    |
| SHOOT OR ACIDIZE    | ABANDON*             |
| REPAIR WELL         | CHANGE PLANS         |
| (Other)             |                      |

## SUBSEQUENT REPORT OF:

|                       |                 |
|-----------------------|-----------------|
| WATER SHUT-OFF        | REPAIRING WELL  |
| FRACTURE TREATMENT    | ALTERING CASING |
| SHOOTING OR ACIDIZING | ABANDONMENT*    |
| (Other)               |                 |

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Move in and rig up PBCP, Inc.
2. Set cast iron bridge plug at 9598' depth and cap with 35' (5 sacks) cement, to shut off perforations from 9648' to 9666' depth,
3. Attempt to salvage 5 1/2" csg. from 7000'
4. Load hole with mud laden fluid.
5. Spot 35 sacks cement thru tubing, 50' below cut off point of 5 1/2" casing.
6. Spot 50 sacks cement thru tbg. at 5360' across top of Glorieta at 5310'.
7. Spot 50 sacks cement thru tbg, at 4001' across 8 5/8" casing shoe at 3951'.
8. Attempt to salvage 8 5/8" csg. from 1200' depth.
9. Pull and lay down 8 5/8" casing.
10. Run tubing, enter 8 5/8" casing and spot 70 sacks cement thru tubing 50' below top of 8 5/8" casing.
11. Spot 70 sacks cement at 434' across 11 3/4" casing shoe at 384' depth.
12. Spot 10 sacks cement at surface.
13. Erect dry hole marker.
14. Level and clean location.

SEE ATTACHED FOR  
CONDITIONS OF APPROVAL

Will tag top of cement plugs spotted across all casing stubs and casing shoes.

18. I hereby certify that the foregoing is true and correct

SIGNED Wm. B. Breeschke

TITLE District Engineer

DATE 1-16-79

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

APPROVED  
AS AMENDED

JAN 24 1979

DISTRICT ENGINEER

\*See Instructions on Reverse Side