

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.C.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. F - 9236
7. Unit Agreement Name 1-A, 2-9-34
8. Farm or Lease Name Midwest State
9. Well No. 1
10. Field and Pool, or Wildcat Vada (Penn)
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	2. Name of Operator Belco Petroleum Corporation
3. Address of Operator 411 Petroleum Building, Midland, Texas 79701	4. Location of Well UNIT LETTER <u>A</u> <u>810</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>9-S</u> RANGE <u>34-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4237' GR	16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PBTD 9705'. Set C.I. bridge plug at 9600'. Spot 2 sx. Class "A" cement on top of C.I. bridge plug. Work 4-1/2" csg. to determine free point. Shoot off 4-1/2" csg. at estimated 8000'. Pump 28 sx. Class "A" cement plug at top of 4-1/2" csg. stub. Load and circulate hole with 9.9# mud (25 sx. salt gel per 100 bbls. salt water). Pull 4-1/2" csg. up to 3940' and spot 32 sx. Class "A" cement plug half in and out of 8-5/8" csg. shoe. Pull out of hole with balance of 4-1/2" csg. Work 8-5/8" csg. to determine free point and shoot off at estimated 2000'. Pull out of hole with 8-5/8" csg. Run 2-3/8" tbg. to 8-5/8" stub and pump 60 sx. Class "A" cement plug. Pull up to 430' and pump 100 sx. Class "A" cement plug half in and out of 8-5/8" csg. shoe. Pull out of hole with tbg. Spot 10 sx. Class "A" cement plug in top of surface csg. Weld on plate and dry hole marker.

*100' plug @ top Clarito
Spot all plugs w/ tubing*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Emory L. Bartimus</u>	TITLE <u>Field Supervisor</u>	DATE <u>March 7, 1975</u>
APPROVED BY <u>Joe D. [unclear]</u>	TITLE <u>Dist. 1, Supv.</u>	DATE <u></u>

CONDITIONS OF APPROVAL, IF ANY