

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. <u>30-025-23843</u>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. NM 0249872 A

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name Duncan Federal Comm.
2. Name of Operator Petroleum Production Management, Inc.	8. Well No. 1
3. Address of Operator Suite 200/Sutton Place Bldg. Wichita, Kansas 67202	9. Pool name or Wildcat Vada Penn
4. Well Location Unit Letter <u>G</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>7</u> Township <u>9-S</u> Range <u>34-E</u> NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4314' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up casing plugging unit. Spot 200' cement at 6330

2. Set cast iron bridge plug in 5 1/2" casing at 6330' (10' above collapsed casing).
Cap with 100' of cement. 20SK PLUS @ 6330 IFB ATTON IS PLUGGED

3. Load hole with salt gel mud.

4. Shoot off and lay down 5 1/2" casing at free point estimated at 5000'.

5. Spot 50 sacks cement plug from 50' inside 5 1/2" casing stub. Tag top of cement.

6. Spot 100' cement plug in 8 5/8" across casing shoe at 3957'.

7. Shoot off 8 5/8" casing at free point and lay down 8 5/8" casing.

8. Spot 70 sack cement plug from 50' inside 8 5/8" casing. Tag top of cement.

9. Spot 70 sack cement plug at 443', 50' below 12 3/4" casing shoe.

10. Spot 10 sacks of cement in 12 3/4" casing at surface. Erect dry hole marker, clean and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gary T. Cothran TITLE District Superintendent DATE 4-1-91

TYPE OR PRINT NAME Gary T. Cothran TELEPHONE NO. 675-2478