

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEMENT OR PLUG DATA TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator
The Maurice L Brown Company

3. Address of Operator
Sutton Place Bldg. Suite 200, Wichita, Kansas 67202

4. Location of Well
UNIT LETTER P 660' FEET FROM THE South LINE AND 667' FEET FROM
THE East LINE, SECTION 12 TOWNSHIP 9S RANGE 33E NMPM.

5a. Indicate Type of Lease
State ☐ Fee ☐

5. State Oil & Gas Lease No.

7. Unit Agreement Name

8. Farm or Lease Name
Sheridan

9. Well No.
1

10. Field and Pool, or Wildcat
Vada Penn

12. County
LEA

15. Elevation (Show whether DF, RT, GR, etc.)
4334.2 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up Permian Basin Casing Pullers, Inc.
2. Attempt to salvage 5 1/2" casing from 7172' depth.
Note: Casing is collapsed and possibly separated at this point. One hundred sacks of Class "H" cement was spotted at 7221' on 7-9-77 and squeezed with 4000#. pressure. If casing can be salvaged from this point, an attempt will be made to tie the casing back together.
3. Load hole with mud laden fluid.
4. Spot 35 sacks cement thru casing at cut off point.
5. Spot 35 sacks cement thru casing at 5367' across top of Glorieta at 5317'.
6. Spot 35 sacks cement thru casing at 3980' across 8 5/8" casing shoe, at 3930'.
7. Attempt to salvage 8 5/8" casing from 1200' depth.
8. Pull and lay down 8 5/8" casing.
9. Run 2 3/8" tubing, enter 8 5/8" csg. and spot 50 sacks cement 50' below top of 8 5/8" casing.
10. Spot 50 sacks cement at 437' across 11 3/4" casing shoe at 387' depth.
11. Spot 10 sacks cement at surface.
12. Erect dry hole marker.
13. Level and clean Location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed Wm. J. Shoemaker TITLE District Engineer DATE 9-13-77

Orig. Signed by Jerry Sexton TITLE Dist 1, Supv. DATE SEP 13 1977

CONDITIONS OF APPROVAL, IF ANY

Expires 3/18/78

RECEIVED

SEP 3 1977

CH. COMM. ON BY COMM.
HUBBS, N. M.