

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 4-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Dry Hole</u>	7. Unit Agreement Name
2. Name of Operator <u>Apexco, Inc.</u>	8. Farm or Lease Name <u>State #7</u>
3. Address of Operator <u>P. O. Box 2299, Tulsa, Oklahoma 74101</u>	9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>B</u> , <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>7</u> TOWNSHIP <u>9S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat <u>Flamingo</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>GR 4392'</u>	12. County <u>Lea</u>

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was drilled to a total depth (4515') with no show of Oil or gas. We plan to plug and abandon the well using the following procedure.

1. Fill the hole with heavy mud laden fluid
2. Set 100 sacks cement plug 4333' - 4487'
3. Set 100 sacks cement plug on top of 5½" stub
4. Set 150 sacks cement plug 2,000 - 2475 (if above 5½" stub salt section)
5. Set 100 sacks cement plug in and out of the 8 5/8" surface casing (337' - 437')
6. Set 10 sacks cement plug in the top of the surface casing
7. Install regulation dry hole market
8. Fill the pits, level the location, & clear location of junk

*24 hour notice before setting bottom Plug.*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Leopold D. Somers TITLE Regional Prod. Manager DATE 11-2-73

APPROVED BY John W. Runyan TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: