

0

O.C. COPIES RECEIVED	
DISTRIBUTION	
IT & FE	
E	
S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - M" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> <b>Dry Hole</b>	7. Unit Agreement Name
2. Name of Operator <b>May Petroleum Inc.</b>	8. Farm or Lease Name <b>wallace</b>
3. Address of Operator <b>One Energy Square, Suite 1000, 4925 Greenville Ave, Dallas, Tx 75206</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>I</b> <b>1129'</b> FEET FROM THE <b>East</b> LINE AND <b>1650'</b> FEET FROM THE <b>South</b> LINE, SECTION <b>31</b> TOWNSHIP <b>11S</b> RANGE <b>38E</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>North Gladiola</b>
11. Elevation (Show whether DF, RT, GR, etc.) <b>3882' GR</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to commence plugging well 5/3/74 using the following procedure:  
TD 11,954'. Estimated cement 8200 sx. Set cast iron bridge plug @ 9600' w/35' of cement on top. Recover 8965' of 5 1/2" csg. Set plug w/65 sx @ 8965'. Pull csg. to 6000' and set plug w/65 sx. Pull csg. to 4500' and set plug w/65 sx. Pull out 5 1/2" csg. Recover 1477' of 8 5/8" csg. Run tbg. to 1477' and set plug w/65 sx. Pull tbg. to 410' and set plug w/75 sx (50' above and below shoe of surface pipe). Set 10 sx plug @ surface. Set dry hole marker.

The proposed plugging procedure above was approved in the O.C.C. District Office 5/2/74 by Mr. Joe Ramey.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Neel A. Taylor TITLE Agent DATE 5/6/74

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: