

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

| |
|--|
| 5a. Indicate Type of Lease |
| State <input checked="" type="checkbox"/> Fee <input type="checkbox"/> |
| 5. State Oil & Gas Lease No. |

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - M (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> | 7. Unit Agreement Name |
| 2. Name of Operator Shell Oil Company | 8. Farm or Lease Name |
| 3. Address of Operator P. O. Box 1509, Midland, Texas 79702 | 9. Well No. 2 |
| 4. Location of Well UNIT LETTER D 660 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 5 TOWNSHIP 12S RANGE 33E NMPM. | 10. Field and Pool, or Wildcat Bagley Penn, North |
| 15. Elevation (Show whether DF, RT, GR, etc.) 4286 DF | 12. County Lea |

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

| | |
|--|--|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> |

SUBSEQUENT REPORT OF:

| | |
|--|---|
| REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| CASING TEST AND CEMENT JOBS <input type="checkbox"/> | OTHER <input type="checkbox"/> |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set cement retainer at 7350'. (Tubing stuck in hole, top of fish at 7408').
- Pump 175 sx Class C cement below retainer. Set 25 sx Class C on top of retainer.
- Shoot 5 1/2" casing at 5850' and pull.
- Load hole with 10# brine.
- Spot 150 sx cement at 5906'.
- Spot 50 sx cement at 4860'.
- Spot 200 sx cement at 3700'.
- Perf 4 holes at 1350'. Set cement retainer at 1325' and pump 125 sx cement, leaving 10' sx on top of retainer.
- Set 5 sx cement plug at surface and set 4" OD steel marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLACING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

| | | |
|---------------------------------|---|---------------------|
| SIGNED <u>G. W. Tullis</u> | TITLE <u>Senior Production Engineer</u> | DATE <u>7-13-77</u> |
| APPROVED BY <u>Darcy Sexton</u> | TITLE <u>Supv.</u> | DATE <u>1/18/78</u> |
| CONDITIONS OF APPROVAL, IF ANY: | | |