

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-5775	
7. Unit Agreement Name	
-	
8. Farm or Lease Name	
State '11'	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Vada Penn	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
R.L. Burns Corp.	State '11'
3. Address of Operator	9. Well No.
3990 1st. Natl. Bank Bldg., Dallas, Texas 75202	1
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <u>i</u> , 1980 FEET FROM THE <u>S</u> LINE AND 1980 FEET FROM THE <u>E</u> LINE, SECTION <u>11</u> TOWNSHIP <u>9-S</u> RANGE <u>33E</u> NMPM.	Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4346.4' Gr.	Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To amend notice of intention to plug and abandon well as follows;

Set cement retainer on tubing at 7500' and pump 100 sx cement below retainer, and 25 sx above retainer.

Find free point in 5 1/2" casing above cement @ 6410'

Cut off 5 1/2" and spot 200' cement plug at cut off, keeping hole full of mud.

Spot 200' cement plug across shoe of 8-5/8" casing at 3890'

Spot 100' cement plug inside 8-5/8" casing at 2300' top of salt.

Find free point of 8-5/8" casing, cut, spot 100' cement plug (50' in open hole, 50' in casing)

Spot 100' cement plug 455-355. (13-3/8 casing shoe 405.)

Spot 15' cement plug at surface with marker.

Express 9-14-77

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Production Engineer DATE May 2, 1977

Orig. Signed By

Jerry Sexton

Dist. L. Supn.

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

100' PLUG ACROSS BASE OF SAN ANTONIO IF NOT BEHIND CSE

RECEIVED

MAY 4 1977

U.S. CONSERVATION COMM.
HOBBS, R. H.