

NEW MEXICO OIL CONSERVATION COMMISSION

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. -----
7. Unit Agreement Name -----
8. Farm or Lease Name Wright '26'
9. Well No. 1
10. Field and Pool, or Wildcat Vada Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator R. L. Burns Corp.
3. Address of Operator 3990 First National Bank Building, Dallas, Texas 75202
4. Location of Well UNIT LETTER <u>G</u> <u>1930</u> FEET FROM THE <u>North</u> LINE AND <u>1880</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>9S</u> RANGE <u>34E</u> N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 4209' RKB

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon this well as follows:

Spot 50 sx cement plug across perfs with tbq.
Load hole with mud.
Find free point of 5-1/2" casing above 6050' (top of cement).
Cut 5-1/2" casing and spot 100' cement at casing stub (50' in OH).
Spot 100' cement plug @ 5455-5355' (Top of Glorietta 5455').
Spot 100' cement plug @ 4120-4020' (8-5/8" shoe 4070').
Spot 100' cement plug @ 2170-2070' (Top salt 2170').
Find free point of 8-5/8" casing; cut, spot 100' cement plug (50' in OH, 50' in casing).
Spot 100' cement plug @ 476- 376' (13-3/8" shoe @ 426').
10 sx cement plug at surface with marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Production Engineer DATE May 2, 1977
APPROVED BY [Signature] TITLE DATE MAY 5 1977
CONDITIONS OF APPROVAL, IF ANY: