

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator BTA OIL PRODUCERS	8. Farm or Lease Name LCH 689-C Ltd
3. Address of Operator 104 South Pecos Midland, Texas 79701	9. Well No. 3
4. Location of Well UNIT LETTER <u>M</u> <u>510</u> FEET FROM THE <u>West</u> LINE AND <u>660</u> FEET FROM THE <u>South</u> LINE, SECTION <u>31</u> TOWNSHIP <u>11-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat N. Bagley (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4309' GL	12. County Lea

<p align="center">16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Procedure

1. Set CIBP @ 8900' w/35' cmt on top.
2. Cut & pull 5-1/2" csg.- Top cmt @ 5806'
3. 100' Cmt plug @ 5-1/2" stub.
4. 100' Cmt plug @ Top Glorietta (5100')
5. 100' Cmt plug @ 3725' (8-5/8" shoe)
6. Cut & pull 8-5/8" csg.
7. 100' cmt. plug @ 8-5/8" stub
8. 100' cmt. plug @ Top salt @ 1700'.
9. 100' cmt. plug @ 354' (12-3/4" shoe).
10. 10 sx plug @ surface.
11. Install dry hole marker.

Verbal approval by John Runyan 8/9/78

certify that the information above is true and complete to the best of my knowledge and belief.

B. K. Newland BOB K. NEWLAND TITLE Regulatory Supervisor DATE 8/14/78
John W. Runyan TITLE Geologist DATE AUG 16 1978