

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1988

5. LEASE DESIGNATION AND SERIAL NO.
NM 23020

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal 33

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT
Sawyer San Andres
(Associated)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec 33, T9S-R38E, NMPM

12. COUNTY OR PARISH
Lea

13. STATE
NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Rhonda Operating Company

3. ADDRESS OF OPERATOR

500 N. Loraine, Suite 1000, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' from the South line and 660' from the West line of
Section 33.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3928.4 KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER ON T-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANT

WATER SHUT-OFF

☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATION. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

WELL SPECS: 8-5/8" casing @ 413; cement circulated to surface.
5-1/2" casing @ 5099'; cement circulated to surface.
Perforations 4952'-5001'.

PROPOSED PROCEDURE:

1. Pull rods, pump and tubing.
2. Set cast iron bridge plug on tubing at 4850'. Cap with 35 feet(4 sacks) cement.
3. Circulate hole with 10% mud laden fluid.
4. Spot 25 sack cement plug 2450'-2235'.
5. Spot 25 sack cement plug 463'-248'.
6. Cut off wellhead 3' below ground level.
7. Place 10 sack cement plug at surface. Set 4" O.D. marker in cement extending 4' above ground level.
8. Clear equipment and junk from location, cover pit.

Estimated start date: 12/27/88.

Notify BLM-Hobbs 24hours prior to commencing.

RECEIVED
DEC 19 12 23 PM '88
CARRIZO AREA

18. I hereby certify that the foregoing is true and correct

SIGNED

Richard Lemon

TITLE Agent

DATE 12/15/88

(This space for Federal or State office use)

APPROVED BY

CHIEF, MINERAL RESOURCES

TITLE

DATE

1-6-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side