

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P.O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
V-61-2	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name	
2. Name of Operator The Maurice L. Brown Company		8. Farm or Lease Name Blue Quail	
3. Address of Operator Suite 200/Sutton Place Bldg. Wichita, Kansas 67202		9. Well No. 1	
4. Location of Well UNIT LETTER <u>C</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1280</u> FEET FROM THE <u>West</u> LINE, SECTION <u>19</u> TOWNSHIP <u>10-S</u> RANGE <u>34-E</u> NMPM.		10. Field and Pool, or WHdeat Vada Penn	
15. Elevation (Show whether DF, RT, GR, etc.) 4218.6' KB 4205.6' GR		12. County Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up PBCP Services, Inc. casing pulling rig.
2. Pick up tubing and go in hole. Tag up on cement plug at 5500' depth. Pull tubing to 4034'. Load hole with salt gel mud.
3. Spot 50 sacks cement through tubing at 4034' to form a 100' cement plug straddling the 8 5/8" casing shoe at 3984'. Tag top of cement.
4. Spot 35 sacks cement ~~XXXX~~ through tubing at 2070' to form a 100' cement plug straddling the top of salt section at 2020' depth.
5. Load hole with salt gel mud and pull out of hole with tubing.
6. Salvage 8 5/8" casing from free point anticipated to be at 1250'.
7. Run tubing to a point 50' below top of the 8 5/8" casing.
8. Spot 75 sacks cement from a point 50' below top of the 8 5/8" casing to form a 100' cement plug. Tag top of cement.
9. Spot 75 sacks cement through tubing at 450' to form a 100' cement plug across the 12 3/4" surface casing shoe at 400' depth. Tag top of cement.
10. Spot 10 sacks cement inside 12 3/4" casing at surface.
11. Erect dry hole marker.
12. Rig down casing pulling rig.
13. Clean and level location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Wm. Groesbeck TITLE District Engineer DATE 4-29-82

ORIGINAL SIGNED BY

APPROVED BY JERRY SEXTON

CONDITIONS OF APPROVAL DISTRICT SUPR.

MAY 4 1982

THE UNIVERSITY OF CHICAGO
LIBRARY
540 EAST 57TH STREET
CHICAGO, ILL. 60637

EX-1170

EX-1170

EX-1170