

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-16	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER SWD	7. Unit Agreement Name
2. Name of Operator Southern Union Exploration Company	8. Form or Lease Name Susco Bough "C" Unit
3. Address of Operator 1217 Main Street, Suite 400, Dallas, Texas 75202	9. Well No. 2
4. Location of Well UNIT LETTER <u>E</u> <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>1980</u> FEET FROM THE <u>North</u> LINE, SECTION <u>27</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or WHDCat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4194.1' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1109.

1. RIH & set a CIBP @ 9500'.
2. RIH & dump 2 sks cement on top of CIBP.
3. RIH w/tubing & circulate the hole w/9.5 ppg mud. POH.
4. RIH & cut off casing @ 7800'. POH w/casing.
5. RIH w/tubing and spot a 50 sk plug from 7850-7750'.
6. Pull up and spot a 60 sk plug from 4025-3925'.
7. Pull up and spot a 65 sk plug from 478-378'. POH.
8. Dig out and cut off wellhead.
9. Spot 5 sk plug @ surface.
10. Install dry hole marker.
11. Clean up location.

100' plug at top of 218

ANTICIPATED PLUGGING DATE: 11/25/85

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED David W. Stevens Drilling & Production Engineer DATE November 1, 1985

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE NOV 5 - 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

NOV 4 - 1985

O.C.D.
HOBBS OFFICE