

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. L-6444	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator PrimeEnergy Corporation		8. Farm or Lease Name Bass State	
3. Address of Operator 731 W, Wadley		9. Well No. 1	
4. Location of Well UNIT LETTER <u>F</u> . <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>2030</u> FEET FROM THE <u>West</u> LINE, SECTION <u>7</u> TOWNSHIP <u>10-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Crossroads, East (SA)	
15. Elevation (Show whether DF, RT, GR, etc.) 3672.7 Gr		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to begin plugging operations on or about September 21, 1992.

1. Set CIBP @ 4850'.
2. Set 35' of cement on top of CIBP.
3. Shoot 4 1/2" casing and attempt to pull.
4. Load hole to 4 1/2" cut-off point with 10# brine with 25# gel per barrel.
5. Set stub plug at 4 1/2" cut-off point; 50' inside casing, 50' outside casing.
5. Tag plug.
7. Set 100' plug at 2850' (Yates)
3. Set 100' plug at 2260 (Anhy)
9. Set shoe plug at 8 5/8" shoe; 50' inside, 50' outside.
10. Set 10 sack plug at surface. Set marker pole.

THE OIL CONSERVATION DIVISION OF THE NEW MEXICO DEPARTMENT OF ENERGY AND MINERALS HAS REVIEWED THE ABOVE INFORMATION AND HAS DETERMINED THAT THE SAME IS IN ACCORDANCE WITH THE REQUIREMENTS OF THE OIL CONSERVATION ACT, N.M.S. 19-1-1, ET SEQ.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

915 682-5600

SIGNED Runeil Seale Runeil Seale

Engineering Assistant

9-15-92

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

SEP 21 '92

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: