

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30 025 30858
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2174
7. Lease Name or Unit Agreement Name State "26"
8. Well No. 3
9. Pool name or Wildcat Vada (Devonian)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Western Reserves Oil Company Inc.	
3. Address of Operator P. O. Box 993, Midland, TX 79702	
4. Well Location Unit Letter <u>K</u> : <u>1,650</u> Feet From The <u>south</u> Line and <u>2,310</u> Feet From The <u>west</u> Line Section <u>26</u> Township <u>10S</u> Range <u>33E</u> NMPM <u>Lea</u> County <u></u>	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4195.8' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
- MIRU well service unit. Pick up 2 7/8" work string & TIH to permanent whipstock set on top of 5 1/2" CIBP @ 12,528'. (Note: CIBP & whipstock in hole due to failed horizontal sidetrack attempt)
 - Circulate hole w/300 bbl 10# brine w/150 sks SW gel. Spot 10 sack cmt plug on CIBP.
 - Pick up tubing to 8,850' & spot 25 sk plug from 8,850' - 8,600' (Wolfcamp)
 - Pick up tubing to 5,400' & spot 25 sk plug from 5400'-5,160'. (Glorieta)
 - TOH w/work string & free point casing. Anticipate free pipe @ approx 4,350. Cut casing w/4" jet cutter & pull and lay down casing.
 - RIH w/tubing to 4,400' & set 100 sk plug from 4,400' to 4,050'. Tag plug.
 - Pick up to 1,950' & spot 35 sk plug to 1,850'. Pick up to 30' & spot 12 sk plug @ surf.
 - Clean Location. Cut off anchors. Install dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Christopher P. Renaud TITLE Engineer DATE 12-13-95

TYPE OR PRINT NAME Christopher P. Renaud TELEPHONE NO. 915 683-5533

(This space for State Use)
ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE DEC 19 1995

CONDITIONS OF APPROVAL, IF ANY:

dp

2011 11 17

