

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPL  
(Other instructions on re-  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

L. C. 062178

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal A

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Milnesand Penn

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 14, 8-S, 34-E, J

12. COUNTY OR PARISH 13. STATE  
Roosevelt New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Lario Oil & Gas Company

3. ADDRESS OF OPERATOR

5013 Andrews Highway, Odessa, Texas 79762

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

1980 feet from South line and 1980 from East Line of Sec.  
SE/4 Sec. 14

14. PERMIT NO.

15. ELEVATIONS (Show whether DE, RT, GR, etc.)

4287 ground level

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)

10-3/4" casing cemented to surface. 7-5/8" casing cemented w/1600 sacks cement. Top of cemen  
by temperature survey 135'. 5 1/2" casing cemented w/200 sacks cement. Top of cement by temper-  
ature survey at 7780'. Cast Iron Bridge plug at 9294'. Perforations- 9270-80, 9194-98.  
Approximate capacity of 5 1/2" casing - 6133 to 9282 = 314 sacks- cement w/314 sacks.  
Set Cement retainer at 6100 - 314 sacks cement. Squeeze cement to fill casing to perforation  
plus excess.

Next cut and pull 5 1/2" casing- cut at 6000'. use 100 feet cement across stub, tag plug, wait  
6 hours. Tubing anchor stuck at 6133', tubing at 6117'.

Next - set 100 feet cement 4750 to 4650, tag plug and wait 6 hours.

Next - Set 100 feet cement plug 2250 to 2150.

Next set 100 feet cement plug 500 to 400 feet.

At surface set 50 feet cement plug.

The estimated date of starting the proposed work will be April 15, 1985.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Area Prod. Supt.

DATE 4-8-85

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

PETER W. CHESTER

DATE

APR 18 1985

\*See Instructions on Reverse Side  
BUREAU OF LAND MANAGEMENT  
ROSWELL RESOURCE AREA

RECEIVED

APR 22 1985

C.C.B.  
NEWS OFFICE