

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

Oil Gas
☐ Well ☒ Well ☐ Other

2. Name of Operator

Yates Drilling Company

3. Address and Telephone No.

105 S. 4th St., Artesia, NM 88210 (505-748-1471)

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1874' FNL & 1874' FWL Section 33-8S-37E

Unit F

5. Lease Designation and Serial No.

NM-03283

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

LMY Federal #2

9. API Well No.

30-041-00275

10. Field and Pool, or Exploratory Area

Allison Penn

11. County or Parish, State

Roosevelt County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well completion or Recompletion Report and Log Form)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. TIH w/ bit & scrapper on tbg. to +/- 9560', TOH.
2. TIH w/ CIBP, set @ +/- 9502', dump 5 sacks of cement on CIBP, TOH.
3. TIH w/ tbg. to +/- 7900', spot 25 sack cement plug, TOH.
4. TIH w/ wireline, perforate @ +/- 4247', 2353', 398', TOH.
5. TIH w/ squeeze retainer #1, set @ +/- 4177', squeeze through retainer w/ 43 sacks of cement, dump 7 sacks on retainer, TOH.
6. TIH w/ squeeze retainer #2, set @ +/- 2333', squeeze through retainer w/ 43 sacks of cement, dump 7 sacks on retainer, TOH.
7. Pump down 4 1/2" casing, try to break circulation to surface, squeeze through perforation @ 398' w/ 40 sacks of cement, leave 10 sacks in 4 1/2" casing.
8. Spot 5 sack surface plug. Minimum 50'.
9. Erect regulation surface marker.
10. Remove equipment and clean location.

NOTE: Mud will be spotted between all cement plugs.

14. I hereby certify that the foregoing is true and correct

Signed Joh Rhar


Title Petroleum Engineer

(This space for Federal or State office use)

Approved by _____

Conditions of approval, if any: _____

Title _____



Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side