

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
OG-90

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name State BA
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER A 990 FEET FROM THE North LINE AND 990 FEET FROM East 34 TOWNSHIP 7-S RANGE 35-E NMPM.	10. Field and Pool, or Wildcat Todd-San Andres Gas
15. Elevation (Show whether DF, RT, GR, etc.) 4203' DF	12. County Roosevelt

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

San Andres perfs 4129-33, 4145-48 & 4173-78 will no longer produce gas in commercial quantities into low pressure sales line and no remedial possibilities exist. We propose to P & A as outlined below:

1. Set 30 sx cement in 4½" csg from 4180' to 3850'.
2. Shoot off and recover 4½" csg from free point (top of cement @ 3500').
3. Set 30 sx cement in and out of 4½" stub.
4. Set 35 sx cement across base of salt @ 2369' (if 4½" stub below this depth).
5. Set 35 sx cement across top of salt @ 2162'.
6. Set 35 sx cement across 8-5/8" shoe @ 333'.
7. Set 10 sx cement in top of well.

Leave 9#/gal gel mud between all plugs. 8-5/8" casing will remain intact. Erect dry hole marker. Clear & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED O.D. Sutch

TITLE Dist. Drlg. Supervisor

DATE 8/13/71

APPROVED BY Leslie A. Clements

TITLE OIL & GAS INSPECTOR

DATE AUG 18 1971

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

AUG 17 1971

**OIL CONSERVATION COMM.
HOBBS, N. M.**