Form 3160-5 (June 1990)

Conditions of approval, if any:

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

5. Lease Designation and Serial No

SUNDRY NOTICES AND REPORTS ON WEL	18	LC 060978
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals		6. Trindian, Allottee or Tribe Name
		7. If Unit or CA, Agreement Designation
SUBMIT IN TRIPLICATE		Milnesand Unit
1. Type of Well		8. Well Name and No.
Oil Gas		310
☐ Well ☐ Well ☐ Other INJECTION		
2. Name of Operator		9. API Well No.
MAERSK ENERGY Inc.		30-041-10059
3. Address and Telephone No.		10. Field and Pool, or Exploratory Area
2424 Wilcrest, Suite 200, Houston, TX 77042-2753, 713	3/783-0376	Milnesand (San Andres)
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State
Unit Letter F: 1980' from the North Line and 1909' from the We Township 8S, Range 35E	est Line SE SW Sec. 19	Roosevelt County, New Mexico
12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
TYPE OF SUBMISSION	TYPE OF ACTION	
☐ Notice of Intent	☐ Abandonment	Change of PlansNew Construction
X Subsequent Report	RecompletionPlugging BackCasing Repair	New Construction Non-Routine Fracturing Water Shut-Off
☐ Final Abandonment Notice	Altering Casing Other	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well-Completion or Recompletion Report and Log form.)
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.}* Work Described: Thru tubing clean-out, reperforating & stimulation of San Andres Injection Well Work Commenced: 05/04/93 Work Completed: 05/07/93 Operations Detail: 1) Cleaned-out well to 4680' with coiled tubing. 2) Spot 22() gallons of S444 Calcium Sulfate Converter Chemical. 3) Perforate San Andres with 4 SPF from: 4604' - 4646' 4664' - 4682' 4) Acidize San Andres perfs with 2500 gallons of 15% HCL acid. 5) Place well back in service.		
	orge Sheffer illing Manager	Date <u>May 18, 1993</u>
(This space for Federal or State affice use) FOR KECURU CINLY Title		0.M. 1. 7. 1993

RECEIVED MAY 2 4 1993

OCD HOBBS OFFICE