

xSubmit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-041-10089
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/> INJECTION		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/> X
2. Name of Operator J. CLEO THOMPSON		6. State Oil & Gas Lease No. 26365
3. Address of Operator 325 N. ST. PAUL, SUITE 4300, DALLAS, TX 75201		7. Lease Name or Unit Agreement Name: MILNESAND UNIT
4. Well Location Unit Letter <u> P </u> : <u> 660 </u> feet from the <u> SOUTH </u> line and <u> 660 </u> feet from the <u> EAST </u> line Section <u> 14 </u> Township <u> 8S </u> Range <u> 34E </u> NMPM County <u> ROOSEVELT </u>		8. Well No. <u> 43 </u>
10. Elevation (Show whether DR, RKB, RT, GR, etc.) <u> 4267' RKB </u>		9. Pool name or Wildcat MILNESAND (SAN ANDRES)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER : ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒
CASING TEST AND CEMENT JOB ☐
OTHER: DRY HOLE MARKER SET ON 6/29/02 ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

- 1.) RIH W/2 3/8 TUBING AND TAG PLUG AT 4456'.
- 2.) CIRCULATE 9.5# SALT MUD TO SURFACE.
- 3.) PULL UP TO 2600' AND CIRCULATE 25 SX OF CLASS "C" CEMENT.
- 4.) WAIT ON CEMENT, TAG PLUG.
- 5.) PULL UP TO 2280' AND CIRCULATE 25 SX OF CLASS "C" NEAT CEMENT.
- 6.) POOH WITH TUBING.
- 7.) RU WIRELINE AND PERFORATE 2 HOLES AT 434'. RD WIRELINE.
- 8.) RIH WITH TUBING AND PACKER, SET PACKER @ 420' AND ESTABLISH INJECTION OR CIRCULATION INTO PERF HOLES.
- 9.) SQUEEZE OR PUMP 25 SX CLASS "C" NEAT CEMENT. FLUSH TO PACKER. UNSEAT PACKER. CIRCULATE 25 SX CEMENT.
- 10.) PULL UP TO 250' AND REVERSE CLEAN. POOH WITH PACKER, WAIT 1 HOUR AND RIH AND TAG CEMENT PLUG. POOH. SET 10 SX SURFACE PLUG.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Jim Stevens* TITLE ENGINEER DATE DECEMBER 12, 2002
Type or print name JIM STEVENS Telephone No. (915)366-8886
(This space for State use)

APPROVED BY *W. E. Parker* TITLE MANAGER DATE DEC 17 2002
Conditions of approval, if any: