

xSubmit 3 Copies To Appropriate District Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
30-041-10089

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.  
26365

7. Lease Name or Unit Agreement Name:  
MILNESAND UNIT

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☐ Other ☐ INJECTION

2. Name of Operator

J. CLEO THOMPSON

8. Well No. 43

3. Address of Operator

325 N. ST. PAUL, SUITE 4300, DALLAS, TX 75201

9. Pool name or Wildcat

MILNESAND (SAN ANDRES)

4. Well Location

Unit Letter P : 660 feet from the SOUTH line and 660 feet from the EAST line

Section 14 Township 8S Range 34E NMPM County ROOSEVELT

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
4267' RKB

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER : ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

- 1.) RIH W/2 3/8 TUBING AND TAG PLUG AT 4456'.
- 2.) CIRCULATE 9.5# SALT MUD TO SURFACE.
- 3.) PULL UP TO 2800' AND CIRCULATE 25 SX OF CLASS "C" CEMENT.
- 4.) WAIT ON CEMENT, TAG PLUG.
- 5.) POOH WITH TUBING.
- 6.) RU WIRELINE AND PERFORATE 2 HOLES AT 434'. RD WIRELINE.
- 7.) RIH WITH TUBING AND PACKER, SET PACKER @ 420' AND ESTABLISH INJECTION OR CIRCULATION INTO PERF HOLES.
- 8.) SQUEEZE OR PUMP 25 SX CLASS "C" NEAT CEMENT. FLUSH TO PACKER. UNSEAT PACKER. CIRCULATE 25 SX CEMENT.
- 9.) PULL UP TO 250' AND REVERSE CLEAN. POOH WITH PACKER, WAIT 1 HOUR AND RIH AND TAG CEMENT PLUG. POOH. SET 10 SX SURFACE PLUG.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jim Stevens TITLE ENGINEER DATE NOVEMBER 25, 2002

Type or print name JIM STEVENS Telephone No. (915)366-8886

(This space for State use)

APPROVED BY CHRIS WILLIAMS ORIGINAL SIGNED BY CHRIS WILLIAMS TITLE GENERAL MANAGER  
Conditions of approval, if any: OC DISTRICT SUPERVISOR

DATE DEC 10 2002