

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E 8948
7. Lease Name or Unit Agreement Name Todd Lower San Andres Unit <i>Sec 31</i>
8. Well No. 3
9. Pool name or Wildcat Todd Lower San Andres Assoc.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <i>Injector</i>
2. Name of Operator PLAINS PETROLEUM OPERATING COMPANY
3. Address of Operator 415 W. Wall, Suite 2110 Midland, Texas 79701
4. Well Location Unit Letter <i>C</i> : <i>330</i> Feet From The <i>North</i> Line and <i>1650</i> Feet From The <i>West</i> Line Section <i>31</i> Township <i>7S</i> Range <i>36E</i> NMPM <i>Roosevelt</i> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) GL 4161

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <i>Convert to WIW</i> <input type="checkbox"/> OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
Pursuant to approval from OCD
Plains plans to convert this well to active injection status for the waterflood development program at the Todd Lower San Andres Unit.

Rig up pulling unit, pick up injection tubing and packer, set packer within 100 feet of uppermost P2 zone perforations, load annulus with inert packer fluid & pressure test to 300 psi and hold for 30 minutes.

Convert TA well to active WIW

I hereby certify that the information above is true and complete to the best of my knowledge and belief.
SIGNATURE *Bonnie Hubbard* TITLE *Engineering Tech* DATE *June 8, 1990*

TYPE OR PRINT NAME TELEPHONE NO.

(This space for State Use) Orig. Signed by *Paul Kautz* Geologist JUN 13 1990

APPROVED BY TITLE DATE
CONDITIONS OF APPROVAL, IF ANY: