

COPIES RECEIVED	
TRIBUTION	
FE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
CG-173

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gene A. Snow	8. Farm or Lease Name Hobbs S
3. Address of Operator 606 So. 13th, Lovington, N. Mex 88260	9. Well No. 1
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>36</u> TOWNSHIP <u>7S</u> RANGE <u>35E</u> NMPM.	10. Field and Pool, or Wildcat Todd Upper Sandstone
15. Elevation (Show whether DF, RT, GR, etc.) 4170 D.F.	12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Drill hole with good mud.
2. Set 4 1/2" C.I. bridge plug @ 4100' capped with 40' of cement.
3. Cut and remove 4 1/2" casing.
4. Set 100' cement plug 50' in and 50' out of 4 1/2" stub.
5. Set 100' cement plug 2050' to 1950'.
6. Set 100' cement plug 400' to 300'.
7. Set 10' cement plug in top of surface casing.
8. Install regulation marker.
9. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Gene A. Snow</u>	TITLE _____	DATE <u>7-13-74</u>
APPROVED BY <u>John R. Ransom</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		