

## OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-1276	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Braden-Deem, Inc.	8. Farm or Lease Name State DB
3. Address of Operator 125 N. Market, Suite 1250, Wichita, Ks 67202	9. Well No. 8
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>25</u> TOWNSHIP <u>7S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat Chavero
15. Elevation (Show whether DF, RT, GR, etc.) 4333RDB	12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 4/11/85 - Set Halliburton SVEZ cement retainer @ 2088 in 4½" casing. Squeeze 200 sks cement thru 2" tubing at 1250 psi. Pull out of cement retainer and leave 50' of cement on top of retainer.
- Lay down 2" tubing.
- Rip 4½" casing collar @ 538'. Spot 75 sks of Class C cement from 540' to 290'. Pull and lay down 16 jts 4½" casing (538').
- 10 sks cement plug in top of 8 5/8" casing. Install dry hole marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Doy C. Deem

SIGNED <u>[Signature]</u>	TITLE <u>President</u>	DATE <u>4/22/85</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>OIL &amp; GAS INSPECTOR</u>	DATE <u>JAN 22 1986</u>
CONDITIONS OF APPROVAL, IF ANY:		