

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-2671	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator The Wiser Oil Company		8. Farm or Lease Name State J
3. Address of Operator P.O. Box 2467 Hobbs, New Mexico 88240		9. Well No. 2
4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>25</u> TOWNSHIP <u>7S</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat Chaveroo SA
15. Elevation (Show whether DF, RT, GR, etc.) 4320 GR		12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Within the next two weeks we plan to plug and abandon the above described well using the following plugging program.

A CI Bridge Plug is now set in the 4½" - 10.5" casing at 4131'. This is 103' above the top perforation.

We plan to put a 3 sx cement plug on top of the bridge plug using a dump bailer on a wire line. Freepoint and shoot off the 4½" casing at approximately 3,000'. This is about 50' above where temperature survey shows top of cement. Pull 4½" casing and go back in hole with a string of 2-3/8" tubing and circulate hole using 25 sx of mud per 100 bbl of fluid. Spot a 100' cement plug in and out of 4½" casing stub. Spot a 100' cement plug at top of anhydrite which is at 1855'. Spot a 100' cement plug in and out of 8-5/8" casing shoe. Spot a 10 sx cement plug at top of hole and install dry hole marker. Clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED B. D. Singletary TITLE District Supt. DATE 4-5-77

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: Expires 10-7-77

RECEIVED

APR 6 1977

OIL CONSERVATION COMM.
HOBBS, N. M.