

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYBUREAU OF LAND MANAGEMENT
FORM 9-331 (Rev. 1-63)
FEDERAL OIL FIELDForm approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

Federal NM 0108997

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Farrell-Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Chaveroo (San Andres)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 30, T-7-S, R-33-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS CONCERNING WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

SEP 14 1983

O. C. D.

ARTESIA, OFFICE

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Champlin Petroleum Company

3. ADDRESS OF OPERATOR

300 Wilco Building Midland, TX 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface660' FEL & 1980' FSL, Sec. 30, T-7-S, R-33-E
State Unit - I

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4441 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)


17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well uneconomical to produce.

Proposed plugging procedure.

Set CIBP @ 4100'+ and cap w/50' cement. Locate 4-1/2" casing free point. (Should be at approximately 1400' ±). Cut off 4-1/2" OD casing at free point. Set 100' cement plug centered at top of 4-1/2" casing stub. Set 100' plug across surface casing shoe @ 361'. Set 10 sx plug in top of surface pipe with marker installed. Fluid between plugs to be 10#/gal mud.

San Andres perfs 4183'-4387'



18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State Seal)

APPROVED BY (PWS-Sgd.) PETER W. CHESTER

CONDITIONS OF APPROVAL, IF ANY:

SEP 13 1983

TITLE

District Superintendent
Drilling & Prod. Opr.

DATE

7/12/83

TITLE

DATE

*See Instructions on Reverse Side