

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease

State ☒ Fee ☐

5. State Oil & Gas Lease No.

OG-929

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Marathon Oil Company	8. Farm or Lease Name State Section 36
3. Address of Operator P. O. Box 2409, Hobbs, New Mexico, 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>7S</u> RANGE <u>33E</u> N.M.P.M.	10. Field and Pool, or Wildcat Chaveroo - San Andres
15. Elevation (Show whether DF, RT, GR, etc.) GL 4323, KB 4334	12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP at 4175'.
- Circulate hole with 9# mud.
- Spot 35' of cement on CIBP.
- Spot 100' plug of cement from 2300' - 2200'.
- Spot 100' plug of cement from 1800' - 1700'.
- Perforate with 4 JSPF at 400'.
- Open bradenhead valve and circulate cement to surface between 4 1/2" and 8 5/8" casing string. Displace cement to 250' with mud.
- Place 30' cement plug at surface.
- Set dry hole marker on well and clean up location.

* Verbal approval given to begin this work by Eddie Seay to Tom Zapatka on October 4, 1985.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Thomas F. Zapatka TITLE Production Engineer DATE October 7, 1985

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT SUPERVISOR TITLE DATE OCT 9 - 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
OCT - 8 1985
O.C.D.
HOBBS OFFICE