

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

CONSERVATION DIVISION

P. O. BOX 2058

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
OC-1395	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator TEXACO Inc		8. Farm or Lease Name New Mexico CT State
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240		9. Well No. 4
4. Location of Well UNIT LETTER <u>C</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>7-S</u> RANGE <u>35-E</u> NMPM.		10. Field and Pool, or Wildcat Todd-Upper San Andres Gas
15. Elevation (Show whether DF, RT, GR, etc.) 4189' (DF)		12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RIGGED UP.
2. SET CEMENT RETAINER @ 4075'. SQUEEZE CASING PERFS 4125'-4196' W/100 SX CLASS H NEAT CEMENT. SPOT 25 SX PLUG ON TOP OF RETAINER TO 4040'.
3. PERFORATE 4 1/2" CASING W/2-JS @ 2000'.
4. SET CEMENT RETAINER @ 1948'. SQUEEZE CASING PERFS @ 2000' W/100 SX CLASS H NEAT CEMENT. SPOT 35' PLUG ON TOP OF RETAINER TO 1913'.
5. SPOT 25 SX CEMENT PLUG FROM 372' - SURFACE.
6. INSTALL DRY HOLE MARKER AND CLEAN LOCATION. WELL PLUGGED AND ABANDONED, 12-19-83.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Kautz TITLE ASST DIST MGR DATE 12-22-83

Original signed by

Paul Kautz

TITLE OIL & GAS INSPECTOR

DATE FEB 29 1984

CONDITIONS OF APPROVAL, IF ANY: