

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>K-4866</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Sun Oil Company - DX Division</b>		8. Farm or Lease Name <b>New Mexico "HH" State</b>
3. Address of Operator <b>P. O. Box 1416 - Roswell, New Mexico 88201</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>L</b> , <b>1980</b> FEET FROM THE <b>S</b> LINE AND <b>660</b> FEET FROM THE <b>W</b> LINE, SECTION <b>20</b> TOWNSHIP <b>7S</b> RANGE <b>36E</b> NMPM.		10. Field and Pool, or Wildcat <b>Todd Lower San Andres</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4159 D.F.</b>		12. County <b>Roosevelt</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. PBSD 4329. Perfs 4284 - 4291. TOC 3650.
2. Load hole with mud.
3. Lay 25 sx. cmt. plug from PBSD to 4200'.
4. Cut off 4-1/2" casing at approx. 3450'.
5. Lay 50 sx. cmt. plug in and out of 4-1/2" stub. This plug will cover top of San Andres at 3520'.
6. Lay 25 sx. cmt. plug 2990 - 3070 to cover Queen. Top at 3053'.
7. Lay 25 sx. cmt. plug 2330 - 2410 to cover Yates. Top at 2387'.
8. Lay 25 sx. cmt. plug in and out base of 8-5/8" csg, 320 - 400. Base at 364'.
9. Place 10 sx. cmt. plug at surface. Install dryhole marker, clean up location.

Estimated Date: 2-14-69

→ Lay this plug over top of 5011

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>F. D. Lebo</b>	TITLE <b>District Engineer</b>	DATE <b>2-7-69</b>
APPROVED BY <b>[Signature]</b>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		