

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions
verse side)FE-
re-Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM-0234351	
2. NAME OF OPERATOR Tom Brown, Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 2608, Midland, Texas 79702		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FNL & 660' FWL		8. FARM OR LEASE NAME Federal	
14. PERMIT NO.		9. WELL NO. 1	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4116'		10. FIELD AND POOL, OR WILDCAT Vada Penn	
		11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA Sec. 33, T8S, R36E	
		12. COUNTY OR PARISH Roosevelt	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

PlugABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We wish to plug this well in the following manner:

Set permanent squeeze tool at 5828'.

Squeeze perfs & collapsed pipe with the number of sacks necessary to get 1000# squeeze.

Cut 4 1/2" at free point.

Set 40 sxs plug in 4 1/2" stub.

Set 40 sxs plug in and out 8 5/8" shoe.

Cut 8 5/8" at free point.

Set 60 sxs plug in 8 5/8" stub.

set 60 sxs plug in and out of 12 3/4" shoe.

set 10 sxs plug in surface.

Please make any changes necessary and advise.

RECEIVED

JUN 25 1989

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

John L. Smith

TITLE

Vice President

DATE

-6-24-80

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

-CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

ACTING DISTRICT ENGINEER