

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIP
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR BTA Oil Producers		8. FARM OR LEASE NAME Pecan 688 Ltd.	
3. ADDRESS OF OPERATOR 104 S. Pecos Midland, Texas 79701		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface		10. FIELD AND POOL, OR WILDCAT Vada - Penn	
14. PERMIT NO. "I" 1980' South & 660' East		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA S-31; T-8-S R-36-E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4111' GL		12. COUNTY OR PARISH Roosevelt	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work).*

Proposed Procedure:

Call USGS, Hobbs, (505/393-3612) 24 hrs. advance. Hole to be filled w/mud laden fluid.

1. Lay down 2-3/8" tbg., Model "R" pkr, cavity & jet pump.
2. Set CIBP @ 9800' w/3 sx cement on top.
3. Cut & pull 5-1/2" csg. T/C @ 8000' (approx). Set 50 sx cmt @ stub. 50 sx cmt @ 5514' (Glorietta); 50 sx cmt @ 4077' (Base Intermediate).
4. Cut & pull 8-5/8" csg. Set 50 sx cmt on 8-5/8" stub; 50 sx cmt @ 377' (Base surface); 10 sx cmt @ surface.
5. Install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Production Clerk

DATE 7-25-73

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

