

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPI
(Other instructions
reverse side)

TE*
re-

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 058185 - B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Tom Brown, Inc.

3. ADDRESS OF OPERATOR
P.O. Box 2608 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.
At surface:
660' FWL & 1980' FSL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Federal C

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Vada Pennsylvania

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 28, T-8-S, R-36-E

14. PERMIT NO. 15. ELEVATIONS Show whether DF, RT, GR, etc.)
4137' GL

12. COUNTY OR PARISH 13. STATE
Roosevelt New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF PULL OR ALTER CASING
 FRACTURE TREAT MULTIPLE COMPLETE
 SHOOT OR ACIDIZE Plug ABANDON*
 REPAIR WELL CHANGE PLANS
 (Other)

WATER SHUT-OFF REPAIRING WELL
 FRACTURE TREATMENT ALTERING CASING
 SHOOTING OR ACIDIZING ABANDONMENT*
 (Other)

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

25' or 35' W/dump bailer

1. Set cast iron bridge plug at 9675' and spot 10 sxs of cement of top of plug.
2. Cut and pull 4 1/2" csg at free point or 8500', whichever is more shallow.
3. Spot cement plug 75' inside and 75' on top of csg stub. Tag plug to insure proper placement.
4. Spot 100' cement plug from 5500' - 5600'.
5. Spot 100' cement plug from 4058' - 3958' at 8 5/8" csg shoe (4008').
6. Cut and pull 8 5/8" csg at free point.
7. Spot 60 sxs cement plug in 8 5/8" csg stub.
8. Spot 100' cement plug from 455' - 355' at 12 3/4" csg shoe (405'). Tag to insure proper placement.
9. Spot 25 sxs cement plug at surface.
10. Install P & A marker.

We will notify you when the location is ready for inspection.

OCT 6 1982

DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
WELLS NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED *[Signature]*

TITLE Southern Division
Operation Supervisor

DATE 10-5-82

This space for Federal or State approval

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:
OCT 15 1982
FOR JAMES A. GILLHAM *See Instructions on Reverse Side
DISTRICT SUPERVISOR

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

RECEIVED
OCT 16 1982
U.S. G.P.O.
1982