

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

N.M. 4039-XB

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different formation.  
Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

APR 30 1980

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Will 693 Ltd.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 34 T-8-S, R-35-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

N.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4177' KE, 4165 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

X

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Move in and rig up PBCP Services, Inc.
2. Pull tubing.
3. Run cement retainer on tubing and set at 6227' (50' above casing separation at 6277' as determined by McCullough caliper survey on 2-11-80).
4. Squeeze cement below retainer with 100 sacks of Class "H" cement.
5. Salvage 5 1/2" casing from free point anticipated to be at 5000' depth.
6. Spot 100' cement plug through tubing from 50' below top of 5 1/2" casing stub. Tag top of cement.
7. Spot 100' cement plug through tubing at 4000' depth (50' below 8 5/8" casing shoe at 4040'). Tag top of cement.
8. Spot 100' cement plug through tubing at 2100' across top of salt section.
9. Salvage 8 5/8" casing from free point anticipated to be at 1000' depth.
10. Spot 100' cement plug through tubing from 50' below top of 8 5/8" casing stub. Tag top of cement.
11. Spot 100' cement plug through tubing at 433' (50' below 12 3/4" casing shoe at 383' depth). Tag top of cement.
12. Spot 10' cement plug inside 12 3/4" casing at surface.
13. Erect dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Wm. Breeschke

TITLE

District Engineer

DATE

4-29-80

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAY 7 1980

\*See Instructions on Reverse Side

for DISTRICT ENGINEER