

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

N. M. OIL FIELD COMM. ON
P. O. BOX 89240
ALBUQUERQUE, NEW MEXICO 87108

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 4039-D

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Nilo 702 JV-D

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 33, T-8-S, R-35-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Petroleum Production Management, Inc.

3. ADDRESS OF OPERATOR

Suite 200/Sutton Place Bldg. Wichita, Kansas 67202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

510' FSL and 1980' FWL, Sec. 33, T-8-S, R-35-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4202' KB 4190' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP at 9650' and cap with 35' cement.
2. Run tubing to bottom and load hole with salt gel mud.
3. Spot 100' cement plug at 7700' Abo at 7730'.
4. Spot 100' cement plug at 5485'. Glorietta at 5435'.
5. Salvage 5 1/2" casing from 8 5/8" casing shoe at 4015'.
6. Spot 100' cement plug from 50' below 5 1/2" casing stub and from 50' below 8 5/8" casing shoe. Tag top of cement.
7. Spot 100' cement plug in 8 5/8" casing at 2224'. Top of Rustler at 2174'.
8. Salvage 8 5/8" casing at free point estimated to be at 800' depth.
9. Spot 100' cement plug from 50' below 8 5/8" casing stub. Tag top of cement.
10. Spot 100' cement plug at 430' depth. 12 3/4" casing shoe at 380' depth.
11. Spot 50' cement plug at surface.
12. Erect dry hole marker.
13. Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Engineer

DATE 1-25-88

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

DATE APPROVED
PETER W. CHESTER

JAN 28 1988

BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA

*See Instructions on Reverse Side