

UNIT STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different section.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

JUN 26 1978

1. ☐ OIL WELL ☒ GAS WELL ☐ OTHER
2. NAME OF OPERATOR
The Maurice L. Brown Co.
3. ADDRESS OF OPERATOR
Suite 200, Sutton Place Bldg., Wichita, Kan. 67202
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
510' FSL and 1980' FWL, Sec. 33, T-8-S, R-35-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4202 KB; 4190' GR

5. LEASE DESIGNATION AND SERIAL NO.

MM 4039-X -D

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Nilo 702 JV-D

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada-Penn

11. SEC., T., R., E., OR NE., OR S.W., AND
SURVEY OR ABRA

33, 8-S, 35-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Repair Casing Leak

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in and rig up well service unit.
2. Pull rods and tubing.
3. Run gauge ring on sand line to 9700' by depthometer measurement.
Note: Casing perforations 9742'-9760'. Recorded PBD 9780'.
Datum: 12' AGL
4. Run Retrievable BP and packer on tubing and set BP at 9650' depth.
Set packer above BP and pressure test BP.
5. Load hole with fresh water.
6. Locate leak in casing. Expect at 5200'.
7. Cement leak below retainer.
8. WOC 24 hours.
9. Drill out retainer and cement.
10. Pressure test casing.
11. Swab well down to 6000' depth and test for leak over night.
12. Wash sand off BP and retrieve BP.
13. Run producing equipment including tubing anchor-catcher and J-Latch on-off tool.

18. I hereby certify that the foregoing is true and correct

SIGNED

Wm. Grossbeck

TITLE District Engineer

DATE 6-23-78

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

JUN 26 1978

A.A.J.

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side