

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on
reverse side)Form approved
Budget Bureau No. 42-31173

5. LEASE DESIGNATION AND SERIAL NO.

NM - 0534316

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Pierce & Dehlinger	8. FARM OR LEASE NAME Union Federal
3. ADDRESS OF OPERATOR 815 Petroleum Bldg., Midland, Texas 79701	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 510' FSL & 1980' FEL	10. FIELD AND POOL, OR WILDCAT Vada Penn
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 34, T-8-S, R-34-E
15. ELEVATIONS (Show whether OF, RT, GR, etc.) 4267' D.F.	12. COUNTY OR PARISH 13. STATE

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was plugged back and recompleted in San Andres which was non productive.
Propose to plug and abandon as follows:

1. Spot 100' cement plug over existing perforations @ 4617 - 4663'
2. Cut off 5 1/2" casing @ approximately 3950' bottom of 8 5/8" casing
3. Spot 100' cement plug @ 5 1/2" cut off
4. Cut off 8 5/8" @ free point estimated @ 1250'
5. Spot 100' cement plug @ 8 5/8" cut off
6. Spot 100' cement plug @ bottom of 12 3/4" surface casing.
7. Spot 10' cement plug in top of surface
8. All plugs will be spotted with mud laden fluid between plugs

19. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Agent

DATE

9-15-75

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

OCT 1 1975
ARTHUR R. BROWN
DISTRICT ENGINEER