

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

NM - 0497735

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
TEXACO Inc.

3. ADDRESS OF OPERATOR
P. O. Box 728, Hobbs, New Mexico, 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface Well is located 1815' ^{S+W} of Section 26,
T-7-S, R-35-E, Unit Letter 'K', Roosevelt County,
New Mexico.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

M. A. Cunningham Fed. NCT-1

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Todd Wolfcamp

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 26, T-7-S
R-35-E

12. COUNTY OR PARISH

13. STATE

Roosevelt

N.M.

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4183' (GR)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

Perforate & Treat Addl. Payx

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

1. Pull pumping equipment. Install BOP.
2. Perforate 5 1/2" csg. liner w/2 JSPF from 7637'-7641' & 7645'-7649'.
3. Set packer @ 5142'.
4. Acidize casing perforations 7596'-7649' w/3000 gals. 15% LSTNE, Acid containing 35# citric acid per 1000 gals., in 3 equal stages using 300# Benzoic Acid Flakes between first and second stages.
5. Flush w/78 bbls. treated fresh water.
6. Swab well.
7. Run pumping equipment, test and return well to production.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Assist. Dist. Supt.

DATE 2-11-76

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY: